

# CHANEL

HORLOGERIE

## WATCH SIZE GUIDE

Most of CHANEL watches are one size and can be adjusted in CHANEL boutiques.

For specific cases such as the Première and Jewellery Watch models, seen below, measure your wrist size and refer to the corresponding chart to find your size. Do not hesitate to contact us for advice.

### MEASURING YOUR WRIST

1. Grasp a length of string or cut a strip of paper.
2. Wrap it around the wrist on which you would like to wear your CHANEL watch.
3. Use a pen to mark the point where it forms a circle.
4. Using a ruler, measure the distance from the end of the string or paper to the mark you made.
5. Add 1.5 cm to the measurement, so that the size of the bracelet is comfortable enough for you. You can then add or remove centimetres if you prefer wearing it tightly or loosely.



PREMIÈRE ROCK TRIPLE ROW	XS	140
	S	150
	M	160
	L	165



PREMIÈRE ROCK SIMPLE ROW	XS	140
	S	150
	M	155
	L	165
	XL	175
	XXL	185



PREMIÈRE MINI WATCHES (H2434)	S	120 - 145
	SDT	125 - 175
	L	145 - 190



CAMELIA JEWELLERY WATCH	XS	150
	S	160
	M	170

PLEASE USE THIS GUIDE AS A REFERENCE.  
CHANEL CANNOT BE HELD RESPONSIBLE FOR ANY MEASUREMENT ERRORS.