
J 12
TOURBILLON
CHANEL

USER GUIDE
ENGLISH

ADJUSTING THE TIME

ADJUSTMENTS

Setting the time

Crown C is normally placed in position 1. Pull the crown out one notch (position 2), turn to move the hands to the desired time. Remember to push the crown back fully to return it to its original position.

Manual winding

In order to ensure the normal functioning of the movement, you are advised to rewind the J12 Tourbillon watch every morning.

This rewinding is carried out by winding the crown in a clockwise direction (position 1) until resistance is felt. This resistance indicates that the movement is completely rewound. It is important never to force when winding.



- A - Hours hand
- B - Minutes hand
- C - Crown