

---

MONTRES JOAILLERIE  
**CHANEL**

USER GUIDE  
ENGLISH

---

### SETTING THE TIME

CHANEL Jewelry Watches are equipped with an adjuster button and can be adjusted manually using the time-setting tool. Should you experience any difficulty, CHANEL boutiques are at your service to answer any questions.

#### ADJUSTING THE TIME

Carefully place the tip of the time-setting tool in the slot found on the back of the watch.

To set the hour, apply pressure for intervals of 2-4 seconds. The hour setting will increase by one increment with each interval.

To set the minutes, apply pressure in brief intervals of one second. The minute setting will increase by one increment with each short interval.

The time-setting tool can only be used to move the hour hand and minute hand clockwise. It is not possible to move them counterclockwise.

