

# CHANEL

HORLOGERIE

## WATCH SIZE GUIDE

Most CHANEL watches are one size and can be adjusted in CHANEL boutiques.

For specific cases such as the Première and Jewelry Watch models below, we invite you to measure your wrist size and refer to the correspondence chart to find your size. Do not hesitate to contact us for advice.

### MEASURING YOUR WRIST SIZE

1. Cut a strip of paper.
2. Wrap it around the wrist on which you would like to wear your CHANEL watch.
3. Use a pen to mark the point where it forms a circle.
4. Using a ruler, measure the distance from the end of the string or paper to the mark you made.
5. Compare your measurement with the chart below to determine your size.

### DETERMINING YOUR WATCH SIZE



PREMIÈRE ROCK TRIPLE ROW	XS	140
	S	150
	M	160
	L	165



PREMIÈRE ROCK SIMPLE ROW	XS	130
	S	140
	M	155
	L	165
	XL	175
	XXL	185



PREMIÈRE MINI (H2434)	S	120 - 145
	STD	125 - 170
	L	145 - 190



CAMÉLIA JEWELRY WATCH	XS	150
	S	160
	M	170